



# Teltonika Installation Instructions

INSTALLING ANYVIZ ON TELTONIKA ROUTERS AND GATEWAYS

## PREREQUIREMENTS

To install the AnyViz Cloud Adapter, you must first complete the device setup:

1. Connect to the device via Ethernet
2. Use Web browser and enter address <http://192.168.2.1> (<http://192.168.1.1> for RUT devices)  
Default username: admin  
Default password: admin01
3. Change the default password when prompted
4. Ensure internet connection is established

## INSTALL CLOUD ADAPTER USING INSTALL SCRIPT

We recommend installing AnyViz with the simple installation script. The script is executed via a single command and can be executed via SSH as well as via the Teltonika web interface.

1. Use Web browser and navigate to routers WebUI
2. Enable advanced mode if firmware is newer then 00.02.X (top right corner)



3. Navigate to SERVICES → CLI
4. Type in "root" to login
5. Type in the same password as used for web interface



6. Type in the following command to start installation

```
wget -qO - http://install.anyviz.io | sh
```

## COMPLETE THE INSTALLATION

After the installation script completed, the CLI output should look like this.

### ^ CLI

```

                                OXXXk
                                kKd

[i] Using cloud adapter optimized for ARM musl
Connecting to download.anyviz.de (40.74.58.131:80)
start.sh          100% |*****|      807   0:00:00 ETA
Connecting to download.anyviz.de (40.74.58.131:80)
anyviz.lua        100% |*****|      333   0:00:00 ETA
Connecting to download.anyviz.de (40.74.58.131:80)
sidebar_anyviz.svg 100% |*****|     2035   0:00:00 ETA
Connecting to download.anyviz.de (40.74.58.131:80)
anyviz.htm        100% |*****|       513   0:00:00 ETA
Connecting to download.anyviz.de (40.74.58.131:80)
anyvizcloudadapter 100% |*****|     3062k   0:00:00 ETA

[✓] Downloaded files successfully
[✓] AnyViz started successfully
root@Teltonika-TRB140:~#
  
```

After the setup has been completed successfully, the web interface of the Cloud Adapter is available under port **8888** (e.g., <http://192.168.2.1:8888>). Now enter the AnyViz Project ID and an onboarding password. For more information, see our [getting started guide](#).

*Note: Since Teltonika firmware 7, unfortunately, integration into the router WebUI menu is no longer possible.*

### ADAPTER CONFIGURATION

AnyViz Project Id



AnyViz Password



For more information about the setup and communication protocols, see the [Universal Cloud Adapter documentation](#).

## UNINSTALLING ANYVIZ CLOUD ADAPTER

To uninstall AnyViz Cloud Adapter, run the following script as described in “Install Cloud Adapter using install script”

```
wget -qO - http://install.anyviz.io | sh -s remove
```

## SUPPORTED DEVICES

Teltonika Networks offers a wide range of devices. The team of AnyViz continuously tests the compatibility with different product lines. Although installation is possible on almost all Teltonika devices, some product lines are only conditionally recommended:

### *TRB1-Series*

The compact gateways (e.g., TRB140, TRB141, TRB142, TRB143, TRB145) are powerful and cost-effective. They are best suited for the installation of an AnyViz Cloud Adapter.

### *RUTX-Series*

The RUTX routers are similar in performance to the TRB1 series. **Warning:** There are currently compatibility problems with firmware version 00.07.03 and newer. Please choose another device or use firmware version 00.07.02.7 until the problem is fixed.

### *RUT-Series (2<sup>nd</sup> Generation)*

The popular RUT2 and RUT9 series has been updated (e.g. RUT200, RUT241, RUT901, RUT906, RUT951, RUT956). The routers now have 128 RAM which is sufficient. The CPU is significantly slower than the TRB1 series, but sufficient for many projects. However, it should be noted that the flash memory is very small, which limits data buffering in the event of a connection failure.

### *Devices with limited recommendation*

The following devices only have 64MB RAM. This is sufficient for small, cost-sensitive projects. It is recommended to prefer a router or gateway with more resources.

- TRB2-devices (e.g., TRB245, TRB255)
- RUT3-devices (e.g., RUT300)
- Discontinued RUT-Series (e.g., RUT240, RUT950, RUT955)

## FURTHER DOCUMENTATION

You will find further information for configuring AnyViz Cloud Adapter at

- Cloud Adapter Documentation: [https://docs.anyviz.io/Universal-Adapter\\_EN.pdf](https://docs.anyviz.io/Universal-Adapter_EN.pdf)
- FAQ: <https://www.anyviz.io/faq/>

## TROUBLESHOOTING GUIDE

In case of malfunction, use the following instructions.

### INTERNET CONNECTION ISSUES

A working internet connection is required for both installation and operation. So first make sure that this works without issues. To test your internet connection, click on **SYSTEM → ADMINISTRATION → TROUBLESHOOT → DIAGNOSTICS**. Enter the address “8.8.8.8” and press **PERFORM**. If you see response packets and 0% packet loss, your gateway is working correctly. Repeat this operation with the address “google.com” to ensure that your DNS-server is working correctly.

#### DIAGNOSTICS

Method

Protocol

Address

**PERFORM**

```
PING google.com (142.250.185.142): 56 data bytes
64 bytes from 142.250.185.142: seq=0 ttl=60 time=13.462 ms
64 bytes from 142.250.185.142: seq=1 ttl=60 time=12.669 ms
64 bytes from 142.250.185.142: seq=2 ttl=60 time=12.773 ms
64 bytes from 142.250.185.142: seq=3 ttl=60 time=12.708 ms
64 bytes from 142.250.185.142: seq=4 ttl=60 time=12.611 ms

--- google.com ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 12.611/12.844/13.462 ms
```

If there are no response packets, please check the following:

- Is an internet gateway configured?
- Is a DNS server configured?
- If the Internet connection is established via a SIM card:
  - Is the APN configured correctly?
  - Is the SIM card activated and does it have sufficient data volume?
  - Is the correct SIM PIN entered?

### ENSURE SUFFICIENT FLASH MEMORY

Flash memory is required both for installation and for storing configuration files. Make sure that at least 2 MB of unused memory is available.

### ENSURE VALID TIME

If the AnyViz Cloud Adapter does not establish a connection despite a working Internet connection, the time of the device should be checked, as this is required for secure TLS encryption. Click on **SERVICES → NTP → GENERAL** and if the current system time differs, click on **SYNC WITH BROWSER**.